

LUXURY VINYL TILE WETROOM INSTALLATION SYSTEM

KITCHEN / LAUNDRY / TOILETS:

1.PREPARE CONCRETE SUBSTRATE

Substrates must be free of all surface contaminants which may include wax, grease, oils, polishes, paints, old adhesive, and curing compounds.

All concrete floors must be tested for moisture content in accordance with the relevant National codes and or Standards prior to the application of works.

2.RLA MOISTURE SEAL (OPTIONAL)

For use where the moisture content exceeds the National nominated moisture content.

3.ROBERTS UNIVERSAL PRIMER

Roberts Universal primer maybe used for non-porous and porous surfaces.

If used over Moisture seal apply as for a non-porous surface.

If universal primer is to be used over a concrete substrate check for porosity levels before applying.

4.LEVELLING COMPOUNDS

Roberts Generale & Primo Levellers are rapid drying self-levelling compounds, both with excellent flow properties formulated for self-levelling differences from 1 to 20 mm and 1-30mm in thickness respectively, used on new or existing internal concrete substrates, they develop a smooth and even surface with high levels of mechanical resistance, ensuring the subsequent installation of floor coverings.

5.ROBERTS 555 TWO PART EPOXY ADHESIVE

Is a Two Part Flexible Polyurethane System, water resistant adhesive, and once cured R555 forms a strong bond that displays high peel and shear strength.

Ideal for wet room installation.

5.KARNDEAN MEGA BOND ADHESIVE

If the use of Karndean mega Bond is to be used, Water spills should be wiped or mopped up immediately to ensure, that failure or compromising the adhesion to the LVT and substrate does not occur.

6.LUXURY VINYL TILE

